

APPLICATION RECOMMENDATIONS

Substrates should be clean, dry and free of dust, dirt, oil or any other contaminants that might prevent proper bonding.

To prevent moisture from being drawn out of WeatherTite Flexible Crown during the curing process, prime masonry surface prior to application. This can be done using WeatherTite Masonry Water Seal in a standard pump sprayer. A spray bottle and water can also be used to prime surface. Spray surface lightly, do not allow priming agent to puddle. Let dry 2-3 minutes then apply WeatherTite Flexible Crown.

Crown Application: With a trowel, begin applying WeatherTite Flexible Crown directly from the pail to the masonry surface. Trowel small section at a time until desired texture is reached. WeatherTite Flexible Crown should be troweled to an average thickness of 1/16" while sustaining a wet edge.

Vertical Application: To cover more area, a masonry float is recommended for application. Apply Flexible Crown to vertical surface and float to a smooth finish. Once applied, Flexible Crown can be easily textured in a number of ways. Below are a few examples of some textures that are easy to achieve.

NOTES:

- Texturing must be completed immediately. Do not allow product to skin over.
- Hot weather conditions may require two people, one to apply the product while the other applies the texture.
- To maintain consistency, keep tools as clean as possible during application.
- For best results, practice different application methods on a test surface such as plywood or cement board.

TEXTURING

Example #1



Smooth textures can be achieved a number of ways. Using a Float will give you a smooth finish. This method will show minor visible tool marks. If smoother texture is desired, mist with water and brush lightly with soft bristle brush.

Example #2



Apply coating as in example #1. Then using a round nose trowel, create swirl pattern. Experiment with different tools to create different patterns.

Example #3



Apply coating as in example #1. Using a dry paint roller (heavier nap rollers will create more texture), begin to roll in a straight up and down pattern. Hint: texture applications are easier with two people.

Always apply texture before product begins to dry.

Example #4



Apply product as in example #3. To create this texture a heavy nap roller is recommended. Once rolling has been completed, lightly brush surface with a soft bristle paint brush.